


15819 - LAGUNA DOUBLE EXTEND DINING TABLE

15978 - LAGUNA DOUBLE EXTEND DINING TABLE - SIKAFLEX

PART LIST :






A. TOP TABLE = 1 PCE

B. LEGS = 4 PCS



HARDDWARE :

C. FLAT WASHER	: 8 PCS
D. SPRING WASHER	: 8 PCS
E. NUT	: 8 PCS
F. WRENCH	: 1 PCE
G. UMBRELLA CUP	: 1 PCE



"IMPORTANT!!
Each joint is unique, precise and will fit flush. You must match the white numbered labels with the corresponding number on opposite piece. Put all pieces together **first** to assure that all the joints fit flush **then** tap in the wooden dowels"