SWING BENCH - 13955



SWING BENCH - 13955

PARTS LIST :

A. BENCH LEG 2 PCS



B. BACKREST 1 PC



C. SEAT 1 PC

D. WOODEN BAR 1 PC

E. FRONT SEAT 1 PC

F. TOP 1 PC



G. LEG ASSEMBLY



H. WOODEN BAR 1 PC

I. TOP SUPPORT A 2 PCS

J. TOP SUPPORT B 2 PCS

HARDWARE :

K. WOODEN DOWELS	16 PCS	
L. HEXAGONAL SCREW A	2 PCS	
M. HEXAGONAL SCREW B	2 PCS	
N. HEXAGONAL SCREW C	2 PCS	
O. HEXAGONAL SCREW D	4 PCS	
P. ALLEN KEY 4mm	1 PC	
Q. ALLEN KEY 5mm	1 PC	
R. SCREW	4 PCS	
S. CHAIN	2 SET	

TOOLS REQUIRED :

T. PHILLIPS SCREWDRIVER (NOT INCLUDED)

NOTE : Use a soft mallet hammer (not included) to prevent marking or denting wood when inserting wood dowels. Do not use excessive force to insert dowels. After inserting wood dowels, minimal sanding may be necessary to make dowel ends flush with surface.